









# 0511 Replacement Parts List



						
M6x12	M5x12	M6x25	Φ6xΦ19	M5	M8	Φ6xΦ12
4x	13x	4x	4x	13x	2x	17x

015

## 0511 Replacement Parts packing data

Item	Exploded Drawing No.	Replacement parts No.	Part Name	Qty.	Carton Size	Qty./Carton	Gross weight	Remark	Scale
序号	爆炸图编号	配件货号	配件名称	数量	包装箱尺寸	每箱件数	每箱毛重	备注	配件比例
1	001	E-0511-001	Lid	1					0.6%
2	002	E-0511-002	Fire bowl	1					0.3%
3	003	E-0511-003	Cooking grill	1					0.4%
4	004	E-0511-004	Charcoal grid	1					0.4%
5	005	E-0511-005	Long leg	2					0.3%
6	005A	E-0511-005A	Dia22 End cap	2					1.0%
7	006	E-0511-006	Wheel leg	2					0.3%
8	007	E-0511-007	Bottom wire	1					0.3%
9	008	E-Wheel-02	Wheel(no cap)	2					1.0%
10	009	E-0511-009	Handle	2					0.8%
11	010	E-0511-010	Airvent for lid	1					0.3%
12	011	E-0511-011	Airvent for firebowl	2					0.3%
13	012	E-0511-012	Short hinge	2					0.3%
14	013	E-0511-013	Long hinge	2					0.3%
15	014	E-Dia22 leg cup	Dia22 leg cup	4					0.3%
16	015	E-0511-015	Screw bag	1					1.0%